


 For setup instructions, commissioning guide, product manuals, technical specifications, certificates and declarations, refer to the product website:  
[www.simrad-yachting.com](http://www.simrad-yachting.com)  
  
[www.bandg.com](http://www.bandg.com)  
  
**Trademark**  
 \*Reg. U.S. Pat. & Tm. Off. and ™ common law marks. Visit [www.navico.com/intellectual-property](http://www.navico.com/intellectual-property) to review the global trademark rights for Navico Holding AS.\*



\* 9 8 8 - 1 1 1 4 5 - 0 0 3 \*

- ### Parts included
- 
- 1 x NAC™ -3 Autopilot Computer - IPX5
  - 4 x Fixing screws
  - 1 x Micro-C Drop cable (male) - 0.6 m
  - 1 x Micro-C T-Joiner
  - 7 x Connectors
  - 1 x 30 Amp fuse
  7. Warranty card & literature pack

