

Motor Box Mounting Diagram

L-Bracket to Underside of Traveller/Box
Horizontal Motor Box
Reverse Motor Rotation

All dimensions in mm

- Notes:
- * Motor must mount on starboard side because otherwise belt will hit L-bracket
 - * Exact position of box determined by belt size and shim used for L-bracket
 - * If motor is moved closer to centerline it may hit the pedestal base

